

DMX Channel Index

impression[®]
120-~~7~~

WWC & GCW



from software version 1.00/03
(Instruction version 1.03)



— since 1994 —

e-mail: service@glp.de
Internet: <http://www.glp.de>

1 DMX Channel Selection (DMX Protocol)

Normal-Mode 12 DMX channels

Channel	Function	Time and Value	DMX	HEX	%	
1) PAN-coarse	0 .. 660°	3,2 s	0..255	00..FF	0..100	
2) PAN-fine	High- Pos ... High- Pos + 2,6°(16 Bit)		0..255	00..FF	0..100	
3) Tilt-coarse	0 .. 300°	1,5 s	0..255	00..FF	0..100	
4) Tilt-fine	High- Pos ... High- Pos + 1,2°(16 Bit)		0..255	00..FF	0..100	
5) White 2/3	White Color, 60x LEDs (either warm- or cold white depending on the system)	0 - 100%	0..255	00..FF	0..100	
6) White 1/3	White Color, 30x LEDs (either warm- or cold white depending on the system)	0 - 100%	0..255	00..FF	0..100	
7) Shutter	Shutter closed		0..15	00..0F	0..5,5	
	Random Pulse effect	slow - fast	16..47	10..2F	6..18,5	
	Up-dimming then Shutter closing (random patterns)	slow - fast	48..79	30..4F	19..31	
	Shutter open then down-dimming (random patterns)	slow - fast	80..111	50..6F	32..43	
	Up-dimming then down-dimming (random patterns)	slow - fast	112..143	70..8F	44..56	
	Strobe effect pause	5s .. 1s	144..199	A0..C7	57..77	
	Strobe effect, slow - fast	1 Hz .. 10 Hz	200..239	C8..EF	78..94	
	Shutter open		240..255	F0..FF	95..100	
8) Dimmer	Dimmer	0 - 100%	0..255	0..FF	0..100	
9) Special	Fan min. as long as temp. < 90°C		224..229	E0..E5	88..89,5	
	RESET (Normal Mode)		250..255	FA..FF	98..100	
10) Move-ment	No movement		0	00	0	
	Movement	Size	Phase			
	PAN	1	0°	01..01	01..01	0,5
		1	90°	02..03	02..03	1,0
		1	180°	04..05	04..05	1,7
		1	270°	06..07	06..07	2,5
	PAN	2	0°	08..09	08..09	3,3
		2	90°	10..11	0A..0B	4,1
		2	180°	12..13	0C..0D	4,9
		2	270°	14..15	0E..0F	5,7
	PAN	3	0°	16..17	11..11	6,5
		3	90°	18..19	12..13	7,3
		3	180°	20..21	14..15	8,0
		3	270°	22..23	16..17	8,8
	PAN	4	0°	24..25	18..19	9,6
		4	90°	26..27	1A..1B	10,4
		4	180°	28..29	1C..1D	11,2
		4	270°	30..31	1E..1F	12
	TILT	size / phase see also PAN		32..63	20..3F	13..25
	PAN / TILT	size / phase see also PAN		64..95	40..5F	26..37
PAN / TILT (inverse)	size / phase see also PAN		96..127	60..7F	38..50	
Circle	size / phase see also PAN		128..159	80..9F	51..62	
Circle (inverse)	size / phase see also PAN		160..191	A0..BF	63..75	
Lying eight	size / phase see also PAN		192..223	C0..DF	76..87	
Random movement	size see also PAN		224..255	E0..FF	88..100	
11) Speed	Pan/Tilt relative movement		0..1	00..01	0..0,5	

Channel	Function	Time and Value	DMX	HEX	%
Pan/Tilt	Pan/Tilt slow – fast Use this channel 14) also for the speed of the movements (channel 13).	Pan Min. 660° = 200s Pan Max. 660° = 3,2s Tilt Min. 300° = 110s Tilt Max. 300° = 1,5s	2..255	02..FF	1..100
12) Zoom	Spot - Flood	10° - 26°	0...255	00...FF	0...100

Compress-Mode 9 DMX channels

Channel	Function	Time and Value	DMX	HEX	%
1) PAN-coarse	0 .. 660°	3,2 s	0..255	00..FF	0..100
2) PAN-fine	High- Pos ... High- Pos + 2,6° (16 Bit)		0..255	00..FF	0..100
3) Tilt-coarse	0 .. 300°	1,5 s	0..255	00..FF	0..100
4) Tilt-fine	High- Pos ... High- Pos + 1,2° (16 Bit)		0..255	00..FF	0..100
5) White 2/3	White Color, 60x LEDs (either warm- or cold white depending on the system)	0 - 100%	0..255	00..FF	0..100
6) White 1/3	White Color, 30x LEDs (either warm- or cold white depending on the system)	0 - 100%	0..255	00..FF	0..100
7) Shutter	Shutter closed		0..15	00..0F	0..5,5
	Random Pulse effect	slow - fast	16..47	10..2F	6..18,5
	Up-dimming then Shutter closing (random patterns)	slow - fast	48..79	30..4F	19..31,5
	Shutter open then down-dimming (random patterns)	slow - fast	80..111	50..6F	32..43
	Up-dimming then down-dimming (random patterns)	slow - fast	112..143	70..8F	44..56
	Strobe effect pause	5s .. 1s	144..199	A0..C7	57..77
	Strobe effect, slow - fast	1 Hz .. 10 Hz	200..239	C8..EF	78..94
	Shutter open		240...249	F0..F9	95..97,5
	RESET	Min. 3 Sec.	250	FA	98
	Shutter open		251..255	FB..FF	99..100
8) Dimmer	Dimmer	0 - 100%	0..255	0..FF	0..100
9) Zoom	Spot - Flood	10° - 26°	0...255	00...FF	0...100

High Resolution (Extended) -Mode 12 DMX Channels

Channel	Function	Time and Value	DMX	HEX	%
1) PAN-coarse	0 .. 660°	3,2 s	0..255	00..FF	0..100
2) PAN-fine	High- Pos ... High- Pos + 2,6° (16 Bit)		0..255	00..FF	0..100
3) Tilt-coarse	0 .. 300°	1,5 s	0..255	00..FF	0..100
4) Tilt-fine	High- Pos ... High- Pos + 1,2° (16 Bit)		0..255	00..FF	0..100
5) White 2/3 coarse	White Color, 60x LEDs (either warm- or cold white depending on the system)	0 - 100%	0..255	00..FF	0..100
6) White 2/3 fine	White - fine/low		0..255	00..FF	0..100

Channel	Function	Time and Value	DMX	HEX	%
7) White 1/3 coarse	White Color, 30x LEDs (either warm- or cold white depending on the system)	0 - 100%	0..255	00..FF	0..100
8) White 1/3 fine	White - fine/low		0..255	00..FF	0..100
9) Shutter	Shutter closed		0..15	00..0F	0..5,5
	Random Pulse effect	slow - fast	16..47	10..2F	6..18,5
	Up-dimming then Shutter closing (random patterns)	slow - fast	48..79	30..4F	19..31,5
	Shutter open then down-dimming (random patterns)	slow - fast	80..111	50..6F	32..43
	Up-dimming then down-dimming (random patterns)	slow - fast	112..143	70..8F	44..56
	Strobe effect pause	5s to 1s	144..199	A0..C7	57..77
	Strobe effect, slow - fast	1 Hz .. 10 Hz	200..239	C8..EF	78..94
	Shutter open		240...249	F0..F9	95..97,5
	RESET	Min. 3 Sec.	250	FA	98
	Shutter open		251..255	FB..FF	99..100
10) Dimmer-coarse	Dimmer	0 - 100%	0..255	0..FF	0..100
11) Dimmer-fine	Dimmer - Low		0..255	0..FF	0..100
12) Zoom	Spot - Flood	10° - 26°	0...255	00...FF	0...100

Locking and unlocking the Control Panel

Please lock and unlock the control panel by pressing the menu keys **MODE & ENTER & UP** at the same time.

Additional features during switching-ON the system

a) 1200Hz Mode (Hold down the **UP- button** during power ON)

After switching ON the system the LEDs will be operated with a Pulse Width Modulation (PWM) of 1200Hz.

In addition all standard setting will be loaded (DMX start address [001], Normal Mode).

b) 600Hz Mode (Hold down the **DOWN- button** during power ON)

After switching ON the system the LEDs will be operated with a Pulse Width Modulation (PWM) of 600Hz.

In addition all standard setting will be loaded (DMX start address [001], Normal Mode).

c) Standard Mode (Hold down the **ENTER- button** during power ON)

After switching ON the system the DMX start address will be set to [001]. All other setting remain unchanged.

Additional Display Indications

As a default you'll find the following additional information in the first row of the LCD display:

XX/X/XX

- 06 = 600Hz / 12 = 1200Hz
- N = Normal Mode / C = Compressed Mode / H = High Res. Mode
- N = Tilt normal / I = Tilt inverted
- N = Pan normal / I = Pan inverted

